

Adding / changing a mark5 recorder

in control/mk5ad.ctl add a line listing IP-address of the Mark5 machines, port to use and connection timeout in centiseconds.

Example:

```
134.104.1.1 2620 500
```