

DBBC Setup and Operation

Uwe Bach

Max-Planck-Institut für Radioastronomie (MPIfR), Bonn



Content


- DBBC hardware characteristics
- Installation of a DBBC
- DBBC software
 - Poly-phase Filter Bank (PFB)
 - Digital Down Conversion (DDC)
- Basic testing
- Field System integration
- VLBI operation



DBBC Outside (front view)




DBBC Inside






DBBC Inside



DBBC Inside






General Features

- 4/8 RF/IF Input out of 16 (4x4) in a range up to 2.2 (3.5) GHz
- 1024/2048 MHz sampling clock frequency
- More personalities for different observing modes
- Input 4/8 polarizations / bands
- Output 4/8 groups of 32 data channel
- Output as VSI interfaces or as 10G Ethernet streams
- Control under Field System or other client console





Installation of a DBBC

How to connect the DBBC






FiLa10G (SA)



- Two independent 10G Ethernet UDP port
- Physical interface optical XFP
- 10G port fully bidirectional
- Installed inside the DBBC box or as stand-alone
- Data rate: 1 – 2 – 4 Gbps each 10G port
- Format mode: RAW, MK5B or VDIF



Connection examples





FiLa10G Software

- FILA10G Files:

- c:\DBBC\bin\timesyncFILA10G.exe (MK5B time set)
- c:\DBBC\bin\vdif_timesyncFILA10G.exe (VDIF time set)
- c:\DBBC\bin\sendstr.exe (serial communication)
- c:\DBBC_conf\FilesDBBC\fila10g_v3.3.1.bit
- c:\DBBC\doc\DBBC2 FILA10G Command set v3.3.1.pdf

Note: a program to sync with a NTP server is required
(eg. NetTimeSetup-314.exe) or new FiLa10G modules
have a GPS module build in that can be used to get the
GPS time.



Setting up the FiLa10G

- Upload of the firmware is
 - automatically made by the DDC/PFB control software (internal FiLa10G)
 - done with an additional Xilinx JTAG programmer using a script for IMAPCT (external FiLa10G-SA)
- Communication is through serial port or Ethernet in the stand-alone version
- Commands available (see document)
- VDIF packet size setting (see document)
- Script files can be used for block of commands (see batch)



Observing modes

- DDC: tunable, channel bandwidth between 1 MHz and 16 MHz, U&L, Continuous cal with 80 Hz synchronization, modes: geo, astro, astro2, w-astro, lba, test
DDC-E: like DDC but bandwidth up to 32 MHz (astro3)
- PFB: fixed tuning, channel bandwidth 32/64 MHz, all U or L depending on the Nyquist zone
- DSC: full $4 \times 512/1024$ MHz, max 8×1024 MHz band direct sampling conversion, all U or L depending on the Nyquist zone
- SPECTRA: 4Kch/IF spectrometer, max 32K channels



Software

How the observing mode is selected

- Using a dedicated firmware
- Using a dedicated control software
- Using a dedicated configuration text file

Software (Windows XP)

Files Structure:

C:\DBBC\bin

→ control software

C:\DBBC\doc


→ manuals

C:\DBBC_CONF\

→ configuration text files

C:\DBBC_CONF\FilesDBBC

→ firmware





Main Menu

- Home
- Products
- Support
- Contacts
- Registration
- Links

Menu utente

- Your details
- Forum
- Invia un articolo
- Amministrazione
- Logout

Home > Support


Downloads

[Overview](#)[Search Downloads](#)[Submit file](#)

Overview

Page: 1 of 1

Number of Categories: 6

[DDC - Tunable 16 BBC](#)

Files: 4

[BASE - General](#)


Files: 4

[FILA10G - 10G Ethernet](#)


Files: 2

[PFB - Polyphase 16 bands](#)

Files: 3

[SPECTRA - Spectrometer](#)

Files: 1

[Technical Notes](#)

Files: 10

search...



Software

- General:

BASE Package

c:\DBBC\bin\DBBC client v3.exe (general client)

c:\DBBC\bin\clock1024.exe (CAT2 1024)

c:\DBBC\bin\clock2048.exe (CAT2 2048)

c:\DBBC\bin\ad9858.exe (CAT1)

c:\DBBC\bin\power.exe (on-off hardware)

c:\DBBC\bin\agc_if.exe (CoMo Unica3 test)

c:\DBBC\bin\agc_if_unica4.exe (CoMo Unica4 test)



Software

- DDC:

c:\DBBC\bin\DBBC2 Control DDC v104.exe (server)
c:\DBBC_conf\dbbc_config_file_104.txt
c:\DBBC_conf\FilesDBBC\dbbc2_ddc_v104.bit
c:\DBBC\doc\DBBC2 DDC command set v104.pdf

- PFB:

c:\DBBC\bin\DBBC2 Control PFB v15.exe (server)
c:\DBBC_conf\dbbc_poly_config_file_15.txt
c:\DBBC_conf\FilesDBBC\dbbc2_pfb_v15.bit
c:\DBBC\doc\DBBC2 PFB command set v15.pdf



DDC configuration file

c:\DBBC_conf\dbbc_config_file_104.txt

Example:

```


1 dbbc2_ddc_v104.bit 597.00 8 ←the first number is indication of ADB1|2, in this case ADB1 is on
1 dbbc2_ddc_v104.bit 682.00 8 IFA and ADB2 on IFB, ADB1 in IFC, no Core2 for IFD
1 dbbc2_ddc_v104.bit 853.00 8 If no Core2 is inserted in the first and second column put 0.
1 dbbc2_ddc_v104.bit 938.00 8 The second parameter is the firmware file name to be used.
2 dbbc2_ddc_v104.bit 597.00 8 The third and fourth parameters are frequency and bandwidth respectively.
2 dbbc2_ddc_v104.bit 682.00 8
2 dbbc2_ddc_v104.bit 853.00 8
2 dbbc2_ddc_v104.bit 938.00 8
1 dbbc2_ddc_v104.bit 597.00 8
1 dbbc2_ddc_v104.bit 682.00 8
1 dbbc2_ddc_v104.bit 853.00 8
1 dbbc2_ddc_v104.bit 938.00 8
0 dbbc2_ddc_v104.bit 597.00 8 Each Core2 board supports 4 bbcs so if not present 0 has to be inserted in
0 dbbc2_ddc_v104.bit 682.00 8 four lines
0 dbbc2_ddc_v104.bit 853.00 8
0 dbbc2_ddc_v104.bit 938.00 8
1 fila10g_v2_1.bit ← if a FILA10G is installed set 1st version 1 (with ACE), 2nd version (without ACE) 2, otherwise 0
1 38000 ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFA
1 38000 ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFB
1 38000 ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFC
1 38000 ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFD
0 38000 ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFE
0 38000 ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFF
0 38000 ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFG
0 38000 ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFH
107 112 0 0 ← phase calibration values
CAT2 1024 ← CAT1|2 and sampling frequency

```



Starting the software

DDC: running DBBC2 Control DDC v104.exe



```
DBBC Control net_v101.exe

core 1 1      dbbc2_v101.bit conf. file    130.990000 lo freq   4 bw filter
core 2 1      dbbc2_v101.bit conf. file    140.990000 lo freq   4 bw filter
core 3 1      dbbc2_v101.bit conf. file    170.990000 lo freq   4 bw filter
core 4 1      dbbc2_v101.bit conf. file    230.990000 lo freq   4 bw filter
core 5 1      dbbc2_v101.bit conf. file    340.990000 lo freq   4 bw filter
core 6 1      dbbc2_v101.bit conf. file    420.990000 lo freq   4 bw filter
core 7 1      dbbc2_v101.bit conf. file    470.990000 lo freq   4 bw filter
core 8 1      dbbc2_v101.bit conf. file    490.990000 lo freq   4 bw filter
core 9 0      dbbc2_v101.bit conf. file    192.990000 lo freq   4 bw filter
core 10 0     dbbc2_v101.bit conf. file    207.990000 lo freq   4 bw filter
core 11 0     dbbc2_v101.bit conf. file    217.990000 lo freq   4 bw filter
core 12 0     dbbc2_v101.bit conf. file    247.990000 lo freq   4 bw filter
core 13 0     dbbc2_v101.bit conf. file    267.990000 lo freq   4 bw filter
core 14 0     dbbc2_v101.bit conf. file    272.990000 lo freq   4 bw filter
core 15 0     dbbc2_v101.bit conf. file    100.990000 lo freq   4 bw filter
core 16 0     dbbc2_v101.bit conf. file    200.990000 lo freq   4 bw filter
FilA10G 0

Reconfigure? y/n -
```

after the Core2 configuration is completed

then run a client ex. **DBBC Client v3.exe or Field System**

**DDC Mode Commands and Form
Table (see documents)**



First tests with the DBBC

- Cabling the DBBC: IF, 1pps, 10 MHz, (80 Hz calibration?)
- Starting the DDC software (server) on the DBBC Windows PC
 - Newest version always available at <http://www.hat-lab.com/hatlab/support> currently v104_2 or v105 for DDC
- Configuration file needs to be edit for your hardware installation.

First functionality can be tested with the DBBC_client or from the FS:

- select different IF inputs for the ADBs and let AGC adjustment work, e.g.

```
> dbbcifa          # for query  
> dbbcifa=2,agc,2 # to set RF input 2, agc on, IF filter 2 (0-500 MHz)
```

read out BBCs set different frequencies, ...

```
> dbbc01          # for query  
> dbbc01=596.00,a,16.00 # to set BBC freq=596 MHz, IFA, BBC  
                           band width = 16 MHz
```



First tests with the DBBC

```
> dbbcifa      # for query  
> dbbcifa=2,agc,2 # to set RF input 2, agc on, IF filter 2 (0-500 MHz)
```

read out BBCs set different frequencies, ...

```
> dbbc01      # for query  
> dbbc01=596.00,a,16.00 # to set BBC freq=596 MHz, IFA, BBC  
band width = 16 MHz
```

```
DBBC client v3.exe  
Enter Command: dbbcifa  
Received from DBBC: dbbcifa/2,0,agc,2,0,38000  
Enter Command: dbbcifa  
Received from DBBC: dbbcifa/2,0,agc,2,0,38000  
Enter Command: dbbcifb  
Received from DBBC: dbbcifb/3,0,agc,1,0,38000  
Enter Command: dbbcifc  
Received from DBBC: dbbcifc/4,0,agc,2,0,38000  
Enter Command: dbbc01  
Received from DBBC: dbbc01/124.490000,a,8,1,agc,255,255,4639,4486,4644,4492  
Enter Command: dbbc02  
Received from DBBC: dbbc02/140.490000,a,8,1,agc,255,255,5140,4758,5117,4745  
Enter Command: dbbcifb=2,agc,2  
Received from DBBC: dbbcifb/2,0,agc,2,0,38000  
Enter Command: dbbcifb  
Received from DBBC: dbbcifb/2,0,agc,2,0,38000  
Enter Command: _
```




Calibration of the DBBC

Calibration or phase optimization is required at the system installation and has to be repeated after a hardware modification in the stack, transportation, or a new firmware. Periodically as a general check.

- Connect a synthesizer tuned to 764 MHz to all IFs.
- Load the firmware to test.
- Point all dbbcifa,b,c,d to this input
- Run the DBBC command: calibration=all
- ... wait



Calibration of the DBBC



...
252 106 3959 16276 10431
253 135 5588 17455 10729
254 161 5276 18712 11039
255

minM1 00050 ele1 **107** minM2 00050 ele2 **79** minM3 00049 ele3 **92** minM4 00051 ele4 **224**

...					
60	270437	872	261803	16988	
61	285347	653	205494	12851	
62	289611	395	169170	10302	
63	301585	352	144859	7090	
64	309365	169	111552	3386	
65	317749	102	95884	2313	
66	322930	79	79745	1817	
67	339064	67	54644	1305	
68	332014	57	37490	881	
69	338031	55	28940	526	
70	324313	54	22799	296	
71	320547	52	17611	223	
72	310049	51	10504	187	
73	276350	51	6440	148	
74	260401	51	4751	106	
75	251864	51	3334	84	
76	204246	51	2061	76	
77	169837	51	1407	60	
78	149612	51	1155	56	
79	97942	51	361	54	
80	74886	51	228	53	
81	55966	50	130	53	
82	46097	51	113	53	
83	28929	51	80	53	
84	21030	53	69	52	
85	7957	55	59	52	
86	5530	55	51	52	
87	2958	57	51	52	
88	2078	61	50	52	
89	1368	80	50	52	
90	734	79	50	52	
91	247	117	50	52	
...					



DDC configuration file

c:\DBBC_conf\dbbc_config_file_104.txt

Example:

```
1 dbbc2_ddc_v104.bit 597.00 8 ←the first number is indication of ADB1|2, in this case ADB1 is on
1 dbbc2_ddc_v104.bit 682.00 8     IFA and ADB2 on IFB, ADB1 in IFC, no Core2 for IFD
1 dbbc2_ddc_v104.bit 853.00 8     If no Core2 is inserted in the first and second column put 0.
1 dbbc2_ddc_v104.bit 938.00 8     The second parameter is the firmware file name to be used.
1 dbbc2_ddc_v104.bit 597.00 8     The third and fourth parameters are frequency and bandwidth respectively.
1 dbbc2_ddc_v104.bit 682.00 8
1 dbbc2_ddc_v104.bit 853.00 8
1 dbbc2_ddc_v104.bit 938.00 8
1 dbbc2_ddc_v104.bit 597.00 8
1 dbbc2_ddc_v104.bit 682.00 8
1 dbbc2_ddc_v104.bit 853.00 8
1 dbbc2_ddc_v104.bit 938.00 8
1 dbbc2_ddc_v104.bit 597.00 8     Each Core2 board supports 4 bpcs so if not present 0 has to be inserted in
1 dbbc2_ddc_v104.bit 682.00 8     four lines
1 dbbc2_ddc_v104.bit 853.00 8
1 dbbc2_ddc_v104.bit 938.00 8
0 fila10g_v2_1.bit ← if a FILA10G is installed set 1st version 1 (with ACE), 2nd version (without ACE 2), otherwise 0
1 38000                         ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFA
1 38000                         ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFB
1 38000                         ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFC
1 38000                         ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFD
0 38000                         ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFE
0 38000                         ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFF
0 38000                         ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFG
0 38000                         ← no unica=0 unica3=1, unica4=2, initial CoMos target values for IFH
                                ← phase calibration values
107 79 92 224                  ← CAT1|2 and sampling frequency
CAT2 1024
```



Test recordings

- Test recordings are good to control the correct sampling (bit statistics), band pass shape, and pcal tones
- The Mark5B comes with a set of programs that allow to check the bit statistics (bstate), do auto- or cross correlations (vlbi2), and extract phase cal (bpcal).
- More power full are the mark5access programs:
m5bstate, m5pcal, m5spec, m5timeseries, ...
Available from the EVN TOG wiki pages
https://deki.mpifr-bonn.mpg.de/Working_Groups/EVN_TOG/DBBC/DBBC_Test_Procedures
- jive5ab allows to stream data directly on a local disk, which avoids to record on diskpacks and use disk2file for small tests.



Connecting a Mark5B(+)

Connect the DBBC VSI1 port to the Mark5B using VSI cable.

Set Mark5B needs to be synced to the 1pps on the VSI cable.

```
tstDIM > clock_set=32:ext
```

```
tstDIM > 1pps_source=vsi
```

```
tstDIM > dot_set=:force
```

```
tstDIM > dot?           # query several times to see if it stays synced
```

Test the quality of the connection

```
DBBC > dbbcform=test,tvg      # starts TVG on the DBBC
```

```
tstDIM > tvr=0xffffffff      # TVR LED should be green.
```

If it is not green it might help to carefully disconnect and reconnect the VSI cable on both ends, sometimes cleaning the connectors with dry air is required.



Test recordings

```
oper@eff-mark5c-1:~$ m5spec
```

m5spec ver. 1.3.1 Walter Brisken, Chris Phillips 20120508

A Mark5 spectrometer. Can use VLBA, Mark3/4, and Mark5B formats using the mark5access library.

Usage : m5spec <infile> <dataformat> <nchan> <nint> <outfile> [<offset>]

<infile> is the name of the input file

<dataformat> should be of the form: <FORMAT>-<Mbps>-<nchan>-<nbit>, e.g.:

VLBA1_2-256-8-2

MKIV1_4-128-2-1

Mark5B-512-16-2

VDIF_1000-64-1-2 (here 1000 is payload size in bytes)

<nchan> is the number of channels to make per IF

<nint> is the number of FFT frames to spectrometize

<outfile> is the name of the output file


<offset> is number of bytes into file to start decoding

The following options are supported

-dbbc Assume dBBC polarisation order (all Rcp then all Lcp)

-nopol Do not compute cross pol terms

-help This list





Test recordings

> bstate

Usage: bstate <input m5b fname> <# frames>

> bstate n13c1_ef_no0002.m5a 200

Ch	--	-	+	++	-	-	+	++	gfact
0	88032	157895	160426	93647	17.6	32.1	31.6	18.7	1.00
1	93899	151616	154405	100080	18.8	30.9	30.3	20.0	0.95
2	92338	153774	156561	97327	18.5	31.3	30.8	19.5	0.97
3	91497	154665	157139	96699	18.3	31.4	30.9	19.3	0.97
4	84797	161299	163577	90327	17.0	32.7	32.3	18.1	1.03
5	89860	155939	158073	96128	18.0	31.6	31.2	19.2	0.98
6	88426	157547	159995	94032	17.7	32.0	31.5	18.8	1.00
7	85429	160711	162749	91111	17.1	32.5	32.1	18.2	1.02
8	89485	153806	157650	99059	17.9	31.5	30.8	19.8	0.97
9	92445	150796	154915	101844	18.5	31.0	30.2	20.4	0.95
10	89559	153929	157131	99381	17.9	31.4	30.8	19.9	0.97
11	92958	151219	155066	100757	18.6	31.0	30.2	20.2	0.95
12	89607	153163	157750	99480	17.9	31.6	30.6	19.9	0.97
13	84856	158081	162791	94272	17.0	32.6	31.6	18.9	1.01
14	84164	159461	163177	93198	16.8	32.6	31.9	18.6	1.02
15	83381	159953	163898	92768	16.7	32.8	32.0	18.6	1.02



Test recordings

- > `vlbi2`

`vlbi file1 file2 -proctime proctime [-rev <0|1>] [-2bit <0|1>] [-tforce <0|1>]`


`2bit: 1 to enable 2-bit input`

`rev: 1 to reverse channels in the plot`

`tforce: 1 to force correlation, ignoring timestamps`

`> vlbi2 n13c1_ef_no0002.m5a n13c1_ef_no0002.m5a -2bit 1 # for autocorrelation`

`> gv dd1.pos`





Test recordings

- > *bpcal*

Usage: bpcal <input m5b fname> <tone freq (KHz)> <# frames>
> *bpcal n13c1_ef_no0002.m5a 2490 500*

integration time 0.078 sec

ch amp phase(dg)

0	1	153.7
1	0	-93.5
2	1	83.2
3	2	-20.0
4	1	-54.9
5	2	-111.1
6	0	-179.6
7	1	-152.4
8	12	-94.5
9	11	-82.5
10	11	-69.3
11	12	-47.9
12	12	24.3
13	12	-58.8
14	10	-154.2
15	9	134.2



Field System

- Basic DBBC support started with FS-9.10.6.
- Starting with FS-9.11.0 the Field System fully supports the DBBC in DDC mode, including continues calibration (switching the noise diode at a rate of 80 Hz) and FS calibration (FIVEPT/ONOFF).
- New features in the DBBC firmware/software always required changes in the FS, FS-9.11.2 to FS-9.11.6
- FS-9.11.8 allows to configure VDIF format and includes support for the Fila10G to be controlled via the DBBC server software V105 and above.
- FS-9.11.9 is just in the queue and will add PFB support (V15).



Field System integration

- The DBBC is fully integrated into the Field System for DDC mode operation. See `/usr2/fs/misc/dbbc.txt` for all details.
- There are the typical control-files that need to be adapted for a new backend and one special for the DBBC IP address:
 - `dbbad.ctl` hold the DBBC IP address
 - `equip.ctl` for the FS
 - `skedf.ctl` for DRUDG
 - Some more in `point.prc`, `station.prc`, and `.Xresources`
- ➔ Once this is done the FS should be ready to DRUDG and observe DBBC schedules.



Field System integration

```
define proc_library 00000000000x
" EUR135 EFLSBERG Ef
" drudg version 2015Jan29 compiled under FS 9.11.07
"< DBBC  rack >< Mark5B recorder 1>
enddef
define exper_initi 00000000000x
proc_library
sched_initi
logsw_jv
mk5=DTS_id?
mk5=OS_rev?
mk5=SS_rev?
mk5=status?
enddef
define setupsx 00000000000x
pcalon
tpicd=stop
mk5b_mode=ext,0x55555555,,8.000
mk5b_mode
form=geo
form
dbbcsx4
ifdsx
cont_cal=on,4
bbc_gain=all,agc,12000
tpicd=no,200
bank_check
tpicd
enddef

define dbbcsx4 00000000000x
bbc01=100.99,a,4.00
bbc02=110.99,a,4.00
bbc03=140.99,a,4.00
bbc04=200.99,a,4.00
bbc05=310.99,b,4.00
bbc06=390.99,b,4.00
bbc07=440.99,b,4.00
bbc08=460.99,b,4.00
bbc09=112.99,c,4.00
bbc10=127.99,c,4.00
bbc11=137.99,c,4.00
bbc12=167.99,c,4.00
bbc13=187.99,d,4.00
bbc14=192.99,d,4.00
enddef
define ifdsx 00000000000x
ifa=4,agc,2,38000
ifb=4,agc,2,38000
ifc=2,agc,2,38000
ifd=2,agc,2,38000
lo=loa,8110.00,usb,rcp,1
lo=lob,8110.00,usb,rcp,1
lo=loc,2100.00,usb,rcp,1
lo=lod,2100.00,usb,rcp,1
enddef
```




Estimate the best IF level

- IF commands (dbbcifa, or ifa (FS)) allow to specify values for the IF target counts where the AGC should adjusted to.
- With an increasing number of DBBCs the best target IF levels seem to cluster around 35000 to 45000 counts, but it might be worth to test those for your DBBC.
 - Best to use with a true receiver with phase-cal on.
 - Then change the attenuation in steps of 2.5 dB over the whole range, while checking detector counts, bbc counts and doing some short 10 sec recordings at the Mark5B
 - Analyse the recordings using bpcal to measure the Pcal-tone amplitudes.



Estimate the best IF level





Estimate the best IF level





Figure 2: Phase-cal amplitude calculated by bpcal over 0.15 sec against detector counts.

Field System integration



Field System integration



VLBI - KOMPOUND / CHECKLISTE
erstellt am: Dienstag, 28. April 2015 6:48 Uhr

Programm-Name:	rk08ww	Art:	cmac
Beginn:	SUN., MAY. 03, 2015	Tag:	123
Ende:	SUN., MAY. 03, 2015	Tag:	123
Startzeit:	15:00:00	UTC	
Endzeit:	16:00:00	UTC	
I. Quelle:	1123+264	Azimuth:	80.8
Elevation:	26.9		
1. Freq		Kontrolle:	
Empfaenger:	860mm		<input type="radio"/>
Version:	LINKE_500MHz		<input type="radio"/>
Vruefen:	ULQ1 = 746	MHz:	<input type="radio"/>
(Empfaengerraum)	ULQ2 = 840	MHz:	<input checked="" type="radio"/>
ESM1:	5		<input type="radio"/>
RX1:	2		<input type="radio"/>
SDH:	Sky_freq = 04850+1dB		<input type="radio"/>
Zusätzlich:	XFFTS: Auf 500 MHz oder 2 GHz Filter einstellen MultiFiBa Mode auf 161, Pegel am xfftsGUI okay?		<input type="radio"/>
ULQ-Select Wahlschalter (S 315) nach unten Phasen-Diskriminatior (S 172-2) um!			
Starten der Schedule mit:	schedule = rk08wwrf #1	(#1= to start at the first line)	<input type="radio"/>
Phasecal: on Bei aktiver Schedule kann mit 'phasecal = on/off' die Phasecal geschaltet werden. Zur Kontrolle sollte in den Bandpass des XFFTS gezoomt werden, dort kann man die Toene in einem Abstand von 1 MHz als Kamm sehen.			
BBC-Pegel:	Abfragen mit bbread	(zeigt auch die BBC Frequenzen an)	<input type="radio"/>
	Einstellung erfolgt automatisch, Pegel counts variable.		
	(benutze Videokonverter: siehe Rueckseite)		
IF-Einstellung:	Abfrage mit ifread		<input type="radio"/>
	Einstellung erfolgt automatisch, Pegel sollte um 38000 liegen		
Toys-messung:	caltsys (Antenne und OBSNP müssen im VLBI Modus sein)	Toys=	<input type="radio"/>
	(Toys in benutzten BBC's okay; ST läuft?)		
(Typische Werte bei schwache Quellen: z.B. 18cm-35-40, 6cm-30-35, 5cm-30, 4cm-25-30, 1.3cm-90-100 (weberlangengig))			
SCHEDULE lauft?:	keine HALT	In 'System Status' Fenster	<input type="radio"/>
Aufnahme auf:	DiskPack (Rueckseite beachten!!!)	Total:	83.654 GB
Korrelator:	**** Moskau ****		
SumLo =	4100.00		
Bemerkungen:			
Nach dem Experiment:	ggf. DiskPack entnommen ggf. Phasecal abgeschaltet ggf. ULQ-Select Wahlschalter (S 315) nach oben!		<input type="radio"/>

Wetter: _____

Baender/DiskPacks:

- | | | | |
|-----|-------|-----|-------|
| 01. | _____ | 05. | _____ |
| 02. | _____ | 06. | _____ |
| 03. | _____ | 07. | _____ |
| 04. | _____ | 08. | _____ |

Probleme, Ausfaelle:

Neu:

Die Schedules werden nicht mehr ausgedruckt, koennen aber bei Bedarf im FSPC1 VNC-Fenster mit:
`/home/open>gv /usr2/sched/Lists/rk08wwsnp.ps`
`/home/open>pir /usr2/sched/Lists/rk08wwsnp.ps`
angeschaut bzw. ausgedruckt werden.


DBBC und IF Einstellung:

```
rk08wwdemux, 0x03030303, 32, 000
tomastiro
ifan1, agc, 1, 38000
ifan3, agc, 1, 38000
```

Einstellung der Videokonverter:

```
procedure dbbc0Id :
bb<<01>>736.00,a,16.00
bb<<05>>736.00,b,16.00
```

Field System integration



Field System integration

ons
01:d
01:a
01#antcn#antenna TRACKING
01#antcn# RFcentre wanted: 4850 Antenna: 4850 synth1,2= 746.000000 840.000000

```

15:15:01/onsource/TRACKING
15:15:01/wx/ 13.5, 966.5, 99.9, 3.5, -89
15:15:01/ifc/4, agc, 2, 38000, 4, 37932
15:15:01/ifa/1, agc, 1, 38000, 33, 38377
15:15:01/bbc01/ 736.000000, a, 16, 1, agc, 49, 53, 11963, 11894, 11467, 11389
15:15:01/bbc05/ 736.000000, b, 16, 1, agc, 62, 61, 12076, 11881, 11586, 11381
15:15:01/bbc09/ 124.490000, c, 8, 1, agc, 202, 211, 11244, 11272, 10319, 10298
15:15:01/bbc13/ 597.000000, a, 16, 1, agc, 63, 103, 11917, 11867, 11927, 11293
15:15:01/disk_pos/2152462417920, 2124641996800, 2124661996800
15:15:01/mk5b_mode/ext, 0x3030303, 1, (32.000), 2
15:15:01;"MultiFiBa mode: Ch08=161 Ch16=161, Attn08=21.5 dB Attn16=22.0 dB
15:15:02/mk5/?dot? 0 : 2015y123d15h15m02.0478s : syncerr_eq_0 : FHG_on : 2015y123d15h15m02.0502s : -0.00
2376:
15:15:02/fmout-gps/ -2.845000e-05
15:15:02:!2015.123.15:29:30
15:15:02#setcl#utime/528271971, 0, 2015, 123, 15, 15, 02, 06, -5, 228, 0.643, 0
15:15:02#setcl#model/old, 1425383710, -32751, 528040589, -5.385, 15.541, rate, 0, unknown, 1, 1
15:15:02;" Disk 00 (1.81e-03, 0.00e+00) is OK!
15:15:02;" Disk 01 (1.75e-03, 0.00e+00) is OK!
15:15:02;" Disk 02 (1.41e-03, 0.00e+00) is OK!
15:15:02;" Disk 03 (2.04e-03, 0.00e+00) is OK!
15:15:02;" Disk 04 (1.83e-03, 0.00e+00) is OK!
15:15:02;" Disk 05 (1.98e-03, 0.00e+00) is OK!
15:15:02;" Disk 06 (2.19e-03, 0.00e+00) is OK!
15:15:02;" Disk 07 (2.00e-03, 0.00e+00) is OK!
```

Trash

System Status

DATE	2015.123.15:16:33	UT	13.6C	1123+264	TRACKING
MODE	15:29:30	NEXT	HUMID	99.87%	RA 11h25m53.7s
RATE					SCHED=rk08wwef LOG=rk08wwef PRBS 966.6mb DEC 26d10m (2000)
					ISYS: IFA IFE IFO IFL CABLE 0.00000s AZ 83.9 EL 29.6
	0 0 0 0				

ERRORS

VLBI-Monitor

VLBI-Monitor V0.995		DBBC
SE-Rechner:	: lauft	OK
DBBC in sync zu Ipp:	: OK	OK
Mark5 in sync zu DBBC:	:	OK
Mark5-System		
Mark5-PC:	: lauft	OK
Diskt:	(XX.....)	B4 T
VNC:	SH40-037	
Letzter Fehler:	DBBC-ZF-Pegel1:	OK
10 FREQUENCIES:		8.0 dB
Logfile:	/usr2/log/rk08wwef.log	
Sonntag,	03.Mai.2015 Bay 123	15:16:31
Verlassen mit:	a (15 sec Verzögerung)	Oct. 2012 by AK/BG/UR

Operator Input

```

>scheduler=rk08wwef,#1
>bbcread
>ifread
>caltsys
>fpointing
>repeat
>
>
```

System Temperatur

	I=0	I=1	I=2	I=3
00	0.0 (IFA)	0.0 (IFE)		
01	796.00	38.3	38.4	
02	0.00	0.0	0.0	
03	0.00	0.0	0.0	
04	0.00	0.0	0.0	
05	796.00	38.8	38.1	
06	0.00	0.0	0.0	
07	0.00	0.0	0.0	
08	0.00	0.0	0.0	
09	0.00	0.0	0.0	
10	0.00	0.0	0.0	
11	0.00	0.0	0.0	
12	0.00	0.0	0.0	
13	0.00	0.0	0.0	
14	0.00	0.0	0.0	
15	0.00	0.0	0.0	
16	0.00	0.0	0.0	


mark5

Time	G8	Z	Check UT
1370	15h52m	3894.130	97.3 14:38:26
037	3h52m	407.716	15.9 15:14:42

BBC

Field... VLBI... oper... xterm VLB... Syst... ERRO... Oper... Syst... mark5 DBBC Mark5B+ Field System Spare

Field System integration



Field System integration

