


```
M grid in the (l,m) plane
--anadir=longitude,latitude,type[,duration]
                                # direction of the analogue HBA beam
--help                          # print this usage
```

The order of the arguments is trivial.

This utility connects to the CalServer to activate the antennas in set --antennaSet containing the selected RCU's. The CalServer sets those RCU's in the mode specified by --rcumode. Another connection is made to the BeamServer to create a beam on the selected antennafield pointing in the direction specified with --digdir.