

Ef	90 cm	UHF	21 cm	18 cm	6 cm	5 cm¹	5 cm²	S/X	X	22 GHz	43 GHz
90 cm	-	3 hours ³	3 hours ³	3 hours ³	45 min ⁴	3 hours ³	3 hours ³	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴
UHF	3 hours ³	-	3 hours ³	3 hours ³	45 min ⁴	5 min ⁶	5 min ⁶	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴
21 cm	3 hours ³	3 hours ³	-	1 min ⁵	45 min ⁴	3 hours ³	3 hours ³	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴
18 cm	3 hours ³	3 hours ³	1 min ⁵	-	45 min ⁴	3 hours ³	3 hours ³	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴
6 cm	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴	-	45 min ⁴	45 min ⁴	1 min ⁵	1 min ⁵	1 min ⁵	1 min ⁵
5 cm¹	3 hours ³	5 min ⁶	3 hours ³	3 hours ³	45 min ⁴	-	1 min ⁵	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴
5 cm²	3 hours ³	5 min ⁶	3 hours ³	3 hours ³	45 min ⁴	1 min ⁵	-	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴
S/X	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴	1 min ⁵	45 min ⁴	45 min ⁴	-	1 min ⁵	1 min ⁵	1 min ⁵
X	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴	1 min ⁵	45 min ⁴	45 min ⁴	1 min ⁵	-	1 min ⁵	1 min ⁵
22 GHz	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴	1 min ⁵	45 min ⁴	45 min ⁴	1 min ⁵	1 min ⁵	-	1 min ⁵
43 GHz	45 min ⁴	45 min ⁴	45 min ⁴	45 min ⁴	1 min ⁵	45 min ⁴	45 min ⁴	1 min ⁵	1 min ⁵	1 min ⁵	-

¹6030 MHz

²6668 MHz

³ Manual change between two prime focus receivers. Working hours only, preferably not every day.

- ⁴ Automatic change between prime and secondary possible at any time. Antenna needs to be pointed to the zenith, changes only once a day.
- ⁵ Changes within a receiver band or between different secondary focus receivers can be done within a minute by setting new LO in prc-file.
- ⁶ Multi-receiver prime focus box, 5 min for automatic rotation into new position.